


#110-000 - PHASOR




#310-000 - POWER SUPPLY





Wire Holes		
O H_A1 NPTH	Zip-Tie Slots	
O H_A2 NPTH	O H_B1 NPTH	+9V
O H_A3 NPTH	O H_B2 NPTH	1 E0
O H_A4 NPTH	O H_B3 NPTH	Power Supply
H_A5	M_B4	GND



POWER SUPPLY	WIRE PADS
ORIGINAL POWER SUPPLY: > 110 / 220 VAC > 30 VAC CT (+/- 15 VAC) > +/- 19.8 VDC (RECTIFIED) > +/- 12 VDC	E1 - INPUT E2 - GND E3 - SW NO (DRY) E4 - SW NC (WET) E5 - SW COM E6 - OUTPUT E7 - NEUTRAL (0 VAC) E8 - LIVE (110-220 VAC)
V(IN) = 9V V(OUT) = 2*V(IN) - 2*V(DIODE) = V(OUT2) = V(OUT) - 2*V(DIODE)	
XD1 — XD5: — 1N5817 for increased voltage — 1N4001 for decreased voltage JP13 / JP14 & XD6 — XD9: — DNP / 1N4001 for decreased — Jumpered for increased voltage	